

ROAD REPAIR SET FOR POTHoles **TURBO UNI**



Aggregates reservoir	tilting body, spreader
Emulsion reservoir	1 100 l
Emulsion heating	PB burner, LPG
Insulation	50 mm
Supercharger	8 - 11 m ³ /min
Working reach of the arm	4 m
Drive	auxiliary engine HATZ

ROAD REPAIR SET FOR POTHoles **TURBO 3000**



Aggregates reservoir	3 m ³
Emulsion reservoir	850 l
Emulsion heating	PB burner, LPG
Insulation	50 mm
Supercharger	8 - 10 m ³ /min
Working reach of the arm	4 m
Drive	auxiliary engine HATZ

ROAD REPAIR SET FOR POTHoles **TURBO 4000 H**



Aggregates reservoir	4 m ³
Emulsion reservoir	1 100 l
Emulsion heating	PB burner, LPG
Insulation	50 mm
Supercharger	8 - 10 m ³ /min
Working reach of the arm	4 m
Drive	auxiliary engine HATZ (communal hydraulics)

It can be used as an inert material spreader during winter	
Spreading width	2 - 8 m
Grit distribution	50 - 300 g

ROAD REPAIR SET FOR POTHOLES **TURBO 5000 COMBI**



Aggregates reservoir	5 m ³
Emulsion reservoir	1,2 m ³
Emulsion heating	PB burner, LPG
Insulation	60 m
Working reach of the arm	5 m
Drive	auxiliary engine HATZ (communal hydraulics)

<i>It can be used as an inert material spreader during winter</i>	
Spreading width	2 - 8 m
Grit distribution	50 - 300 g

ROAD REPAIR SET FOR POTHOLES **TURBO 7000**



Aggregates reservoir	7 m ³
Emulsion reservoir	1,4 m ³
Emulsion heating	PB burner, LPG
Insulation	60 m
Working reach of the arm	5 m
Drive	auxiliary engine HATZ (communal hydraulics)

<i>It can be used as an inert material spreader during winter</i>	
Spreading width	2 - 8 m
Grit distribution	50 - 300 g

ROAD REPAIR SET FOR POTHOLES **TURBO ELEFANT**



Aggregates reservoir	5 m ³
Emulsion reservoir	1,2 - 1,4 m ³
Emulsion heating	PB burner
Insulation	60 m
Extendable arm	on the front clamping plate
Working reach of the arm	5 m
Drive	auxiliary engine HATZ (communal hydraulics)

<i>It can be used as an inert material spreader during winter</i>	
Spreading width	2 - 8 m
Grit distribution	50 - 300 g